




3.2 Installer Account Registering






- Create the first installer account. This will also generate a domain that is named after the company name.



- To create multiple installer accounts for the same company, log in to the FusionSolar app and tap **New User**.



3.2 Setup Wizard



Tips

SUN2000P-375W SUN2000-450W-P

Optimizer model	Smart PV safety box model	Inverter model
SUN200P-375W	SmartPSB200L	SUN200L-2/3/3.68/4.4/4.9/5KTL
SUN200P-450W-P	NA	SUN200-2/3/3.68/4.4/4.9/5KTL/L1
SUN200P-450W-P	NA	SUN2000-3/4/5/6/9/10KTL-MT
SUN200P-450W-P	NA	SUN2000-8/10/12/15/17/20KTL-M2

Note: Use devices strictly according to the preceding table. Do not mix up the devices.

Causes of missing optimizers

- The DC switch is OFF.
- Some PV strings are not connected to the inverter.
- The inputs of some optimizers are not connected to PV modules.
- The outputs of some optimizers are not connected to PV strings.
- The input and output of some optimizers are reversely connected.

Warning

If the system requires a change, for example, adding, deleting, or replacing an optimizer, adjusting the physical position of an optimizer, or adjusting PV strings, power off the entire system, wait for 5 minutes, and then perform the change operation. After the system is changed, you must perform the quick settings or optimizer search again and update the physical layout diagram. Otherwise, problems such as missing optimizers, failure to locate optimizer faults, or system faults may occur.

In a non-cascading scenario, the step of Searching for cascaded inverters is not involved.

Cascading of multiple inverters with the SUN2000-(3KTL-20KTL)-M0 as the master inverter

Select the corresponding communication settings based on the Smart Dongle.

WLAN communication

Quick settings

Device detection Completed

Setting basic parameters Connect to mgmt sys

The access to the management system must be authorized by the customer. For details, see the [privacy policy](#).

Monitor the PV plant through the management system.

Ethernet

Select a router that can connect to the Internet and enter the router password.

WLAN list

Password Router: WLAN password

Previous Next

FE communication

Quick settings

Device detection Completed

Setting basic parameters Connect to mgmt sys

The access to the management system must be authorized by the customer. For details, see the [privacy policy](#).

Monitor the PV plant through the management system.

Ethernet

If Ethernet is disabled, the network cable is not connected. Reconnect the network cable.

Setting parameters for the inverter to connect to the router

DHCP

Previous Next

4G communication

Quick settings

Device detection Completed

Setting basic parameters Connect to mgmt sys

The access to the management system must be authorized by the customer. For details, see the [privacy policy](#).

Monitor the PV plant through the management system.

Dongle parameter settings

APN mode Automatic

Network mode 4G/3G/2G automatic selection

PIN

Parameter	Description
APN mode	Set SIM card parameters. Obtain the parameters from the SIM card carrier.
APN	
APN dialup number	
APN user name	
APN user password	When APN mode is set to Automatic , APN, APN dialup number, APN user name, and APN user password are not displayed. When APN mode is set to Manual , APN-related parameters are displayed. You can set the parameters.
PIN	

- The PIN code is usually at the back of a SIM card.
- If the automatic dialing is successful, 4G parameters are not displayed.

Previous Next

Quick settings

Quick settings

Device detection Completed

Setting basic parameters Connect to mgmt sys

Quick settings are completed. Check the following

- Connect to mgmt sys Success
- Sync param Success
- SN:XXXXXXXXXXXX Success
- SN:XXXXXXXXXXXX Success
- Inverter SUN2000-XXX 1pcs Grid connected

Tips

Connect your phone to the Internet. Turn off WLAN and enable cellular mobile network.

Confirm

Previous Next

Add a plant.

Create Site

Add plant

Connect to existing plant

Later

Add plant

Set basic info

Country/Region

Company

Plant name

Total string capacity(kWp)

Grid-connected 09/29/2020

Plant address Enter or locate

Plant time zone

Owner Owner name

Contact method Phone/ Email

Owner's authorization obtained

If the content you entered involves third-party personal information, obtain authorization in advance.

Next

Add plant

Set basic info

Connect device

Device SN

Added devices

Device SN	4f6gsc1234567890	
Device type	SmartLogger	
Device model	V100R002C00B030	

Connected devices >

Previous Submit

Create an owner account.

Plant Statistics

Setup wizard New user

Enter a plant name.

No Optimizer	2.205 kWp	3.68 kWh	Normal
Full Optimizer	2.205 kWp	3.81 kWh	Normal

New user

*Company xxx

*Role Owner

*Plant

*Username

*Password

Photo

Phone

*Email

Owner role: power station homepage, equipment management, user account settings and power station information settings

If the content you entered involves third-party personal information, obtain authorization in advance.

Home Maintenance Device Me

Cancel OK

3.3 Checking the Device Status

• Checking the Device Status Using Device Commissioning

Mobile phone connected to the Internet

English

FusionSolar

Username or email

Password

Forgot password?

Log in

No account?

Plant Statistics

demo

Announcements

Commissioning

Plant management

User management

Company info

Settings

Home Maintenance Device Me

Mobile phone not connected to the Internet

English

FusionSolar

Username or email

Password

Forgot password?

Quick Guide

User manual

Commissioning video

Replace certificate

Login setting

Commissioning

CANCEL

Note: If the mobile phone connected to the Internet, tap the screen does not display **Device commissioning**.

User manual

Commissioning video

Replace certificate

Login setting

CANCEL

Check the device status using device commissioning.

Connect

Connection record

Identity authentication

SN: XXXXXXXXXXXX

Advanced User

Enter your password

Log in as **Advanced User**.

Cancel Log in

SUN2000-XXXX-XX

Communication status: No communications component

Management system: Connection failed

Alarm management

Quick settings

Device Monitoring

Maintenance

Settings

Power adjustment

Device monitoring

Power curve

Energy yield statistics

• Checking the Device Status Remotely.

Plant Statistics

demo

Announcements

Commissioning

Plant management

User management

Company info

Settings

Home Maintenance Device Me

Full Optimizer

Weather --

3.73 kWh Yield today

149.04 kWh Yield this month

No Optimizer

2.205 kWp

3.68 kWh

Full Optimizer

2.205 kWp

3.81 kWh

PV module

Load


Grid

Home Maintenance Device Me Overview Statistics Plant layout


3.4 Physical Layout Design on the FusionSolar App (Optional, for Scenarios with Optimizers)

Step 1. Check that the SN labels of the Smart PV Optimizers have been attached to the Huawei physical layout template.

Installation positions of PV modules and optimizers



Huawei Physical Layout Template



Template shooting


How do I take a photo of a template?



1. Keep your phone parallel to the template and take a photo in landscape mode.
2. Ensure that the four positioning points in the corners are in the frame.
3. Ensure that the QR code is attached within the frame.

Step 2. Check that the Smart PV Optimizers are successfully searched.


1. Open the **FusionSolar** app, log in to intl.fusionsolar.huawei.com using the installer account, choose **My > Device commissioning**, and connect to the WLAN hotspot of the solar inverter.
2. Select **installer** and enter the login password.




Template Photographing Requirements

- Place the template on a flat surface and take a photo horizontally.
- Ensure that the four positioning points are within the range shown in the picture.
- Ensure that the QR code is attached in the box and does not exceed the frame.
- Ensure that the QR code is clear without reflection or shadow. Otherwise, the recognition accuracy will decrease.
- If the QR code cannot be identified, you can manually bind the SN.


Step 3. Set optimizer physical layout



method 1: Tap **Identify image** for automatic layout.



method 2: Tap **Add PV modules** for manual layout.



Step 4. Bind Smart PV Optimizers

Select a PV module to be bound to the optimizer.

Select the corresponding optimizer.

After the layout is complete, tap **Submit**.

Step 5. Check the Smart PV Optimizer status.

Tap a corresponding PV string and check the optimizer status.

Unbind the optimizer.

Physical Layout FAQs


Scenario	Suggestion
Before the physical layout is generated, the Identification result contains an abnormal optimizer.	Check whether the networking is successful.
Before the physical layout is generated, the number of optimizers in the Identification result is incorrect.	1. Take photos again as required. 2. If some QR codes fail to be identified, manually bind QR codes after the layout diagram is generated.
Before the physical layout is generated, the number of pure PV module in the Identification result is incorrect.	1. Check whether the dotted box in the corresponding box is painted black as required. 2. Take photos again as required. 3. If some pure components fail to be identified, manually repaint them after the layout diagram is generated.
The physical layout has been generated, but some QR codes fail to be identified. The QR codes that are not identified are incorrectly identified as pure PV module.	Manually select unidentified QR code and bind it to PV module
The physical layout has been generated. Most QR codes fail to be identified. The QR code is incorrectly identified as a pure PV module.	Delete the generated physical layout and take a photo as required.
The physical layout has been generated, but the pure PV module is not identified.	Manually add pure PV module.
The physical layout has been generated, but some templates are not identified.	In the generated physical layout, click image identification to identify the missing templates.

If the system requires a change, for example, adding, deleting, or replacing an optimizer, adjusting the physical position of an optimizer, or adjusting PV strings, power off the inverter, wait for 5 minutes, and then perform the change operation. After the system is changed, you must perform the quick settings or optimizer search again and update the physical layout diagram. Otherwise, problems such as missing optimizers, failure to locate optimizer faults, or system faults may occur.


3.5 Physical Layout Design on the FusionSolar WebUI (Optional, for Scenarios with Optimizers)

Log in to the <https://intl.fusionsolar.huawei.com> as **installer** user.

1. On the **Homepage**, click a PV plant to enter the **Single Power Plant** page.




2. Click **Layout**.




3. Upload the physical layout.

Method1: through the WebUI.




Method2: through the app.



4. Click **Generate Layout** to generate a physical layout diagram.

← Back


Plant Layout



5. Click **Save** to save the generated physical layout diagram.


Result

×




6. If some QR codes are not recognized, manually bind the optimizers.

Physical Layout





← Layout Configuration





(Optional) Manual configuration of physical layout diagram.


1. Drag the PV module to the physical layout area, increase the number of widgets, and adjust the angle based on the site requirements.



2. Select a device in the device list, and drag it to the corresponding icon position to bind the device to the icon.









3. Click  on the toolbar to save the settings.




Right-click a PV module that has been bound to a device to unbind the device.

3.6 Power Adjustment




3.7 Grid-tied Point Control





Limit or reduce the output power of the PV power system to ensure that the output power is within the specified range.


Power factor closed-loop control



Grid connection with zero power



Export limitation



Grid connection with zero power (single-phase)

Active power

For a single inverter, set Closed-loop controller to Inverter.

Control mode: Grid connected with zero power

Closed-loop controller: SDongle/SmartLogger

Limitation mode: Total power

Power adjustment period: 1.0 s


Maximum protection time: 5.0 s

Power control hysteresis: 0.100 kW


Active power output limit for fail-safe: 0.0 %

Communication disconnection fail-safe:

[Collapse](#)



Inverter output	3 kW
Load consumption	3 kW
Output	0
Input	0



Inverter output	5 kW
Load consumption	6 kW
Output	0
Input	1 kW

Grid connection with zero power (three-phase)

Limitation mode - Total power

Active power

For a single inverter, set Closed-loop controller to Inverter.

Control mode: Grid connected with zero power

Closed-loop controller: SDongle/SmartLogger

Limitation mode: Total power


Power adjustment period: 1.0 s

Maximum protection time: 5.0 s

Power control hysteresis: 0.100 kW

Active power output limit for fail-safe: 0.0 %

Communication disconnection fail-safe:




Example: export limitation power value is 0. $\Sigma P = 0$

	Phase 1	Phase 2	Phase 3	Total
Production	2 kW	2 kW	2 kW	6 kW
Consumption	1 kW	2 kW	3 kW	6 kW
Export	1 kW	0	0	1 kW
Import	0	0	1 kW	1 kW

Limitation mode - Single-phase power

Collapse




Example: export limitation power value is 0. Each phase exported power < 0

	Phase 1	Phase 2	Phase 3	Total
Production	1 kW	1 kW	1 kW	3 kW
Consumption	1 kW	2 kW	3 kW	6 kW
Export	0	0	0	0 kW
Import	0	1 kW	2 kW	3 kW

3.8 Energy Storage Control (L1 inverter + LG battery)

Battery parameters


You can choose **Maintenance** > **Add/Remove device** > **Battery** on the home screen to set the full discharging capacity.



Control mode

Choose **Power adjustment** > **Energy storage control** > **Control mode** and perform operations as required.

- If this parameter is set to **Fixed charge/discharge**, the battery is charging or discharging during the configured period. A maximum of 10 time periods can be added.



- If this parameter is set to **Maximum self-consumption** and the inverter is connected to a power meter, the inverter provides output power for local loads before feeding the remaining power to the power grid.




- If this parameter is set to **Time-of-use**, the battery is discharged when the electricity price is high and charged when the electricity price is low. A maximum of 10 time periods can be added.

Charge from grid


Choose **Power adjustment** > **Energy storage control** > **Charge from grid**. After **Charge from grid** is enabled:

- When the battery capacity is 2% lower than the **End-of-discharge capacity**, the system forcibly charges batteries from the power grid. The charging power is limited to 1 kW. When the battery capacity is 2% higher than **End-of-discharge capacity**, the system stops charging batteries from the power grid.
- Except the **Maximum self-consumption** control mode, if the PV power is less than the preset charge power, the system charges batteries from the power grid. The charge power is limited to 2 kW. When the battery capacity is higher than **Grid charge cutoff SOC**, the system stops charging batteries from the power grid.





Forced charge/discharge

Choose **Power adjustment** > **Energy storage control** > **Forced charge/discharge**.




Maximum self-consumption



3.9 AFCI

Description


If PV modules or cables are incorrectly connected or damaged, electric arcs may be generated, which may cause fire. Huawei inverters provide unique arc detection in compliance with UL1699B-2018 to ensure the safety of users' lives and property. This function is enabled by default. The inverter automatically detects arc faults. To disable this function, log in to the FusionSolar app, enter the **Device commissioning** screen, choose **Settings > Feature parameters**, and disable **AFCI**.



Clearing alarms

The AFCI function involves the DC arc fault alarm.


The inverter has the AFCI alarm automatic clearance mechanism. If an alarm is triggered for less than five times within 24 hours, the inverter automatically clears the alarm. If the alarm is triggered for more than five times within 24 hours, the inverter locks for protection. You need to manually clear the alarm on the inverter so that it can work properly. Log in to the FusionSolar app and choose **My > Device commissioning**. On the **Device commissioning** screen, connect and log in to the inverter that generates the AFCI alarm, tap **Alarm management**, and tap **Clear** on the right of the DC arc fault alarm to clear the alarm.



3.10 DRM (Australia AS4777)

According to Australia AS4777.2-2015, the inverter must meet the requirements of the Demand Response Mode (DRM) function, where DRM0 is mandatory.

This function is disabled by default.



Mode	Port on the Inverter	Required Or Not
DRM0	DI1 and GND of the COM port	<ul style="list-style-type: none"> When S0 and S9 are switched on, the inverter should be shut down. When S0 is switched off and S9 is switched on, the inverter should be connected to the power grid.

